



m550

Moto Cam
機車行車記錄器 (GPS)
机车行车记录器

User Manual
使用說明書
使用说明书



This product is designed with waterproof. However, it is forbidden to use a strong jet of water to rinse or flush the product. The warranty will be invalid if the damage is caused by this reason.

本產品具備防水設計，但嚴禁使用高壓水槍沖洗產品，若因此導致產品故障，不在保修範圍內！

本产品具备防水设计，但严禁使用高压水枪冲洗产品，若因此导致产品故障，不在保修范围内！



m550

**Moto Cam
User Manual**

Contents

About this Guide	4
Regulatory notices.....	4
Prohibition of co-location.....	4
WEEE Notice.....	4
CE Regulatory Notice	4
Notes on Installation	4
1 Introduction	7
1.1 Feature.....	7
1.2 Package Contents	7
1.3 Product Overview.....	8
1.3.1 Host.....	8
1.3.2 Easy Pad.....	8
1.4 Getting Started	9
1.4.1 Insert the Memory Card	9
1.4.2 Remove the Memory Card.....	9
1.5 Installation.....	10
1.5.1 Connect host and accessories	10
1.5.2 Installation position	11
1.5.3 Install power cable.....	12
1.5.4 Setting and calibration.....	12
2 Setting.....	13
2.1 Download Go Moto app.....	13
2.2 Wi-Fi Connection.....	13
2.3 Use Go Moto app	14
2.3.1 Camera preview, record, snapshot.....	15
2.3.2 Playback, delete, download	16
2.3.3 Local Album	18
2.3.4 Camera Setting	19
3 SuperCar 2.0.....	20
4 Specification.....	21

About this Guide

The content in this document is for information purpose and is subject to change without prior notice. We have made every effort to ensure that this User Guide is accurate and complete.

However, no liability is assumed for any errors or omissions that may have occurred. The manufacturer reserves the right to change the technical specifications or accessories without prior notice.

Regulatory notices

This document provides country- and region-specific non-wireless and wireless regulatory notices and compliance information for your product. Some of these notices may not apply to your product.

Prohibition of co-location

This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

WEEE Notice

Disposal of Waste Electrical and Electronic Equipment and/or Battery by users in private households in the European Union



WEEE



Battery

This symbol on the product or on the packaging indicates that this cannot be disposed of as a household waste. You must dispose of your waste equipment and/or battery by handling it over to the applicable take-back scheme for the recycling of electrical and electronic equipment and/or battery. For more information about recycling of this equipment and/or battery, please contact your city office, the shop where you purchased the equipment or your household waste disposal service. The recycling of materials will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and environment.

CE Regulatory Notice

The product herewith complies with the requirements of IEC 62368-1:2014, the EMC Directive 2014/30/EU, the RED-Directive 2014/53/EU and the RoHS Directive 2011/65/EU.

EU Health Protection: This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Notes on Installation

1. Keep the wire and host mounted away from the high-voltage ignition coil.
2. Do not bend the wires and connectors severely while installation.
3. Do not touch the lens with your fingers. Finger grease may be left on the lens and will result in unclear videos or pictures. Clean the lens on a regular basis.
4. Use the attached power cable and wires for installation only. Please do not use other brand of power cable or wires to avoid equipment burn or explosion.

5. Please seek for professional shops and technicians for installation.

Caution

- ❖ Due to local laws and vehicles safety considerations, do not operate the camcorder while driving.
- ❖ Set up time zone, time and date accurately before you use this camcorder.
- ❖ Please use SuperCar software under the condition that Electronic Map are functioning normally.
- ❖ The firmware function in the camcorder is for reference only, drivers are advised to exercise discretion based on actual road conditions.
- ❖ The results of GPS positioning are only for reference, and should not affect the actual driving situation. The camcorder also cannot ensure the positioning accuracy.
- ❖ GPS positioning accuracy may differ depending on weather and location such as high buildings, tunnels, undergrounds, or forests. GPS satellite signals cannot pass through solid materials (except glass). Tinted window will also affect the performance of the GPS satellite reception.
- ❖ GPS reception performance on each camcorder may differ. The camcorder cannot determine the accuracy of the positioning results from different hardware.
- ❖ The values displayed in this camcorder, such as speed and position, may be inaccurate due to the influence of surrounding environment. They are for your reference only.
- ❖ This product is used only for non-commercial use, within the maximum limits permitted by applicable law. We do not take any responsibilities for the loss of use of the product.
- ❖ This camcorder gets warm when in use; this is normal.
- ❖ Improper use or operation of the product may result in damage of the product or its accessories and void the warranty.
- ❖ Wi-Fi Signals are unable to pass through the building. The limit of signal transmission is 5m.
- ❖ Wi-Fi Operation Channel: Ch1~Ch13
- ❖ The product employs wireless data communication which may interfere, or be interfered by, a near-by camcorder.
- ❖ Never use this camcorder in the vicinity of a microwave oven or at places where there is radio interference.
- ❖ Radio wave reception may be worsened in specific environments.
- ❖ Please be advised that if another camcorder is also using the same 2.4GHz band as this product, the processing speed of both camcorders may slow down.
- ❖ This product gets warm when in use; this is normal.
- ❖ Improper use or operation of the product may result in damage of the product or its accessories and void the warranty.

- ❖ The radio frequency (RF) generated by this RF electronic camcorder may cause adverse effects on the operation of other electronic camcorders and result in malfunctioning. Wireless transmitters and circuitry may also interfere with other electronic camcorders. Therefore, do observe the following precautions:
 - Aircraft: Never use a radio transmitter when you are in an airplane. Please switch off the Wi-Fi function of the camcorder.
 - Vehicle: The radio frequency transmitted by this camcorder may affect the electronic system in a motorized vehicle. Please consult the manufacturer or dealer of your vehicle on the possible effect.
 - Pacemaker: In order to prevent any potential interference to a pacemaker, anyone who uses a pacemaker should be advised, that, when using this camcorder, a minimum distance of 15cm (6 inch) should be kept between the camcorder and the pacemaker; and never put this camcorder in a chest pocket. In case of any doubt of interference, switch off the camcorder immediately.
 - Medical Camcorder: If you use a personal medical camcorder, consult the camcorder manufacturer or your physician to confirm if your camcorder is sufficiently shielded from the RF transmission of this camcorder.
 - Medical Facilities: Hospitals and medical institutes may use facilities that are sensitive to an external RF energy. Observe such instructions when the medical care personnel or any posted sign requests you to switch off any camcorder that may interfere the radio frequency.
 - Explosion sites or any location with a posted sign: In order to prevent interfering with an explosion activity, observe all the signage and instructions in the Explosion Area or in a zone with a “Switch Off 2-way Radios” sign by switching off camcorders that may interfere with the radio frequency.
- ❖ HP Inc. is NOT responsible for the loss of any data/content during operation.
- ❖ Product application disclaimer
Please scan the QR code below and read the product application disclaimer carefully.



When you start using the system, it is assumed that you agree to the above statement.

1 Introduction







Thank you for purchasing this advanced Moto Cam. This product is specifically designed for real time video recording when riding scooter.

1.1 Feature

- Intelligent Noise Reduce, suppress surrounding noise efficiently
- Dual waterproof camera, super high resolution
- Sony's starves sensor
- Wi-Fi and friendly app
- Host and accessories all waterproof
- Hot key to lock the file
- Freely position GPS in any better reception
- Collision and topple-over detection, auto emergency recording


1.2 Package Contents

The package contains the following items. In case there is any missing or damaged item, contact your dealer immediately.

Host	Front/rear camera	GPS
		
Easy Pad	Power cable	Installation Kit
		


1.3 Product Overview

1.3.1 Host



編號	名稱	編號	名稱
1	Reset	5	Green: to connect GPS
2	microSD slot	6	Blue: to connect rear camera
3	5in1 connector	7	Yellow: to connect Easy Pad
4	Red: to connect power cable	8	Black: to connect front camera

1.3.2 Easy Pad



No	Item	Function
1	LED indicator - front camera	-LED always on: power on (standby) -LED flash: front camera is in recording -LED flash quickly: speed cam alert. *Note
2	LED indicator - rear camera	-LED always on: power on (standby) -LED flash: rear camera is in recording
3	Microphone	For Intelligent Noise Reduce
4	Lock file / Wi-Fi	-short press: to lock the file -long press: turn on Wi-Fi


Note:

1. The speed cam alert function must have the speed cam map datum of the country or region built into the GPS of the device. If there is no built-in map datum, this function will not work. If GPS is not installed, this function has no effect either. The speed cam alert function is for reference only, and it's not guaranteed to cover all speed cam spots on the driving route. Please make own judgments based on actual road conditions while driving.
2. The speed cam map datum depending on shipping area. Please contact distributor whether if it's built-in or not for your area.

1.4 Getting Started

1.4.1 Insert the Memory Card

Insert memory card with the gold pins facing forward, and the nameplate of the host is toward up, see the picture as below,



1.4.2 Remove the Memory Card

Turn off the scooter's engine, and the camera will power off accordingly. Once the camera is completely powered off, you can remove the memory card from memory slot.

Note:


1. Don't remove or insert the memory card while the camera is in working status. This may damage the memory card or cause data lose.
2. Support microSD card speed V30 or higher and capacity 16GB or greater. (support up to 128GB)
3. Please use Go Moto app to format the memory card and sync the date and time before the initial use.
4. Please regularly format memory card and sync date/time. (Recommend once a month)

1.5 Installation



Below installation is for reference only. Please contact professional shops and technician for installation.

1.5.1 Connect host and accessories

Connect host with power cable, front camera, rear camera, GPS and easy pad according to connector's colors.




1.5.2 Installation position



No	Item	Installation position
1	Front camera	To be fixed on scooter's head or the central of front case.
2	Easy pad	To be fixed on the front handle. (refer to above drawing) DO NOT put the Microphone toward to front end.
3	GPS	To be fixed on a good reception of front handle..
4	Rear camera	To be fixed on the car plate or rear handle.
5	Installation	Use Installation Kit to mount the host, accessories and wires. Refer to above image and the wiring route to install all items.
6	Host and wires	Put and fix the host and accessories' wires in the cabinet. Use Velcro to fix the host on the inner side of cabinet; it's convenient to remove the host and take out memory card to check. *When installation is completed, use Go Moto app to calibrate topple-over detection. (Tilt Detection).

1.5.3 Install power cable



1.5.4 Setting and calibration

When installation is completed, please use Go Moto app to synchronize date/time, set up time zone, adjust view angle of camera, and calibrate topple-over detection (tilt detection). For details of menu setting, please refer to chapter 2. setting.

2 Setting

2.1 Download Go Moto app

The Moto Cam allows you to connect to the smart phone to preview, set-up camera, synchronize date/time and calibrate topple-over detection. When using the Moto Cam for the first time, download and install **[Go Moto]** app from your smart phone.



1. Download **Go Moto** application from Google Play Store or Apple App Store.
2. Complete the installation.

APP layout and features may be changed subject to different software versions. Please refer to Google Play or APP Store for update.

2.2 Wi-Fi Connection

1. Press the button on Easy Pad for 3 seconds to turn on Wi-Fi.
2. Using the Wi-Fi function of your smart phone, search for the Moto Cam ID "hp_m550_123456" from the list (last 6 numbers are system random numbers). Enter default password **12345678** to connect with Moto Cam.
3. Use downloaded app Go Moto to start setting or operating other functions.

- Note:
1. Wi-Fi is default ON for 3 minutes when power on. If there is no connection with app within 3 minutes, Wi-Fi will be turned off automatically. To turn on again Wi-Fi, long press Easy Pad button for 3 seconds.
 2. The smart phone shall be within a maximum of a 5m distance from the host without any buildings in between.
 3. The language of the [Go Moto] app will be consistent with your smart phone, beyond the language options, the App will be activated with default language.

2.3 Use Go Moto app







Touch [Go Moto] icon to activate the application. The main screen will pop up. Follow the below instruction to operate this application.



2.3.1 Camera preview, record, snapshot

You can use this feature to preview, record or take snapshot.




	icon	Description
1		Start/stop recording
2		Snapshot (no matter in front camcorder or rear camcorder preview, once you touch this icon, both of front and rear camcorder will take photo.)
3		Switch front and rear camcorder preview
4	Front Camera Setting	Rotate camera preview image
5	Rear Camera Setting	Rotate camera preview image





2.3.2 Playback, delete, download

You can use this feature to playback or delete the file saved in camcorder, or to download the file from camcorder to your mobile device.



1. Touch the icon [Video playback] or [Picture playback].
2. The files saved in the camcorder will be displayed on your smart phone. Camcorder will stop recording for a few seconds until your smart phone finishes reading the saved files from camcorder.
3. Touch the preview image of video or picture to playback.
4. Touch the right top corner "Select" and pick up the files that you want to delete or download, and touch below icon to execute.



	Icon	Description
1		Switch front and rear camcorder
2		Download the file from camcorder to your mobile device
3		Delete
4		Exit

Note:


1. If you find the video playback without audio, please check if you turn on Voice Record on the Setting. If you do turn it on, it means the smart phone itself doesn't support the video decoding. It's not the problem of the file. We recommend you to install a free app software such as VLC to playback the file.
2. Deleted files cannot be recovered. Ensure the files have been backed-up before deletion.
3. Picture and video files could be downloaded to the internal memory of your smart phone. Use the application program in your smart phone to view the file.
4. The downloaded videos or pictures will be saved in the album of your smart phone, at the mean time it will create a new folder "Go Moto". You can preview the files from the album.

2.3.3 Local Album

You can use this feature to playback or delete the file that you download in your smart phone.



1. Touch icon [Local Album].
2. Pick up the file that you want to playback.



3. The downloaded videos or pictures will be saved in the album of your smart phone, at the mean time it will create a new folder "Go Moto". You can preview or delete the files from the album.

Note:

1. Deleted files cannot be recovered. Ensure the files have been back-up before deletion.
2. If you find the downloaded files unable to playback or without audio, which means the smart phone itself does not support the video decoding. It's not the problem of the file. We recommend you to install one free App software such as VLC to playback the file.

2.3.4 Camera Setting

You can use this feature to set up your car camcorder.



1. Touch icon [Camera Setting].
2. Refer to the below table for details of menu items and available menu options.

Menu Option	Description	Available options
Phone Synchronization	To synchronize date/time with camcorder.	Yes / No
Set Time Zone	To set up time zone in order to auto sync date/time once GPS is positioned.	GMT -12 ~ GMT +12
Speed Unit	Set up speed unit.	Km/h, mph
Car Speed Watermark	To turn on or off car speed watermark.	On / Off
Speed Cam Alert	When this function is enabled and GPS is positioned, once your scooter is approaching speed cam, the LED on Easy Pad will flash quickly. *If there is no speed cam map datum built-in, the LED will not flash quickly.	On / Off
Record Interval	Save respective video files in a length of the selected duration.	1 min / 3 min / 5 min
Voice Record	Setting voice record in the video.	On / Off
Intelligent Noise Reduce	If turn on this feature, it can suppress surrounding noises and deliver human voice more clear.	On / Off
Anti-flicker	Domestic power supply varies by area. It is recommended that you should check the "Table of voltage and frequency of different countries" for the correct setting.	50Hz / 60Hz
Tilt Detection	When the host is installed completely, please use this function to calibrate topple-over detection.	OK / Cancel
Default	Return to factory default setting.	Yes / Cancel
Format	To format the memory card, all the files in the camcorder will be deleted.	Yes / Cancel
Wi-Fi Setting	To set up Wi-Fi password	
Firmware Version	Indicates the current camcorder's firmware version.	
APP Version	Indicates the current application version.	

3 SuperCar 2.0

Please click this link to download particular video/GPS player SuperCar 2.0:
https://ftp.digilife.com.tw/SuperCar_2.0/SuperCar_2.0.zip.



No.	Item
1	Front Camera Playback
2	Browse File
3	Capture
4	Fast Backward
5	Playback / Pause
6	Fast Forward
7	Volume
8	Playback Duration

No.	Item
9	G-sensor Value
10	Rear Camera Playback
11	Software Version
12	Map(riding route)
13	File List
14	Language and Map Change

Note:
 1. To display the route on Electronic Map, please make sure the internet is connected before starting the video playback.
 2. The SuperCar 2.0 software is only applicable to Windows operating system.

4 Specification

Item	Description
Image sensor	1/2.8" Sony's starves sensor
Effective pixels	1920 (H) x 1080 (V)
Storage media	Supports microSD 16GB above and class V30 speed or greater, up to 128GB
Lens	Wide Angle Fixed Focus lens Aperture: F/1.55
Focus range	1.5m~Infinity
Satellite System	GPS (External)
Video file	Front camera: 1080p/30fps HDR Rear camera: 1080p/25fps HDR
	Format: TS
Still image (Photograph)	Use app to take photo
	Format: DCF (JPG)
G-Sensor	3-Axis G-Force sensor
ISO	Auto
White Balance	Auto
Microphone	Built-in
Speaker	N/A
Power	Super Capacitor
Operating Temperature	-10° ~ 60° C
Operating Humidity	20 ~ 70% RH
Storage Temperature	-20° ~ 70° C
Host Dimensions	80 x 50 x 20 mm
Host Weight	Approx. 84g

Built-in IEEE 802.11g/n(HT20) Wi-Fi chip: RTL8188FTV

Frequency range	2412~2484MHz
Wi-Fi Channel	Ch1~Ch13
Wi-Fi Max. output	18dBm



m550

**機車行車記錄器 (GPS)
使用說明書**

目錄

Regulatory notices.....	2
禁止同置.....	2
WEEE 通知.....	2
CE Regulatory Notice.....	2
NCC 警語.....	3
安裝須知.....	3
安全注意事項.....	3
1 導論.....	5
1.1 功能.....	5
1.2 包裝內容.....	5
1.3 產品概要.....	6
1.3.1 主機.....	6
1.3.2 線控.....	6
1.4 使用儲存媒體.....	7
1.4.1 插入記憶卡.....	7
1.4.2 取出記憶卡.....	7
1.5 安裝.....	8
1.5.1 主機連接配件及電源線.....	8
1.5.2 安裝位置.....	9
1.5.3 安裝電源線.....	10
1.5.4 調整與校正.....	10
2 設定.....	11
2.1 下載應用程式.....	11
2.2 Wi-Fi 連線.....	11
2.3 使用應用程式.....	12
2.3.1 相機預覽/翻轉畫面, 錄影及拍照.....	13
2.3.2 檔案播放, 刪除及下載.....	14
2.3.3 手機相簿.....	16
2.3.4 相機設定.....	17
3 SuperCar 2.0.....	18
4 規格.....	19
5 限用物質含有情況說明書.....	20

有關本手冊

本文件之內容只供參考，並得以隨時變更不需要事先通知。本公司已盡全力確保本使用者手冊正確與完整。但有任何錯誤或遺漏概不負責。製造廠保留不需事先通知，逕自變更技術規格或配件之權利。

Regulatory notices

This document provides country- and region-specific non-wireless and wireless regulatory notices and compliance information for your product. Some of these notices may not apply to your product.

禁止同置

本產品及其天線不得在同一地點與任何其他天線、發射器同置或共同操作。

WEEE 通知

歐盟有關使用者處分私人家庭廢電子與電機產品和/或電池之指令



WEEE



Battery

產品上或包裝上有此一符號，表示此產品不能做為家庭廢棄物處理。您必須依據相關之電子與電機產品和/或電池回收辦法之規定，處分您的廢電子與電機產品和/或電池。有關這類產品和/或電池的回收細節，請聯絡當地的市政府、您購買該產品的商店或您的家庭廢棄物處理公司。材料之回收有助於保護自然資源及確保能以保護人類健康與環境之方式回收。

CE Regulatory Notice

The product herewith complies with the requirements of IEC 62368-1:2014, the EMC Directive 2014/30/EU, the RED-Directive 2014/53/EU and the RoHS Directive 2011/65/EU.

EU Health Protection: This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

NCC 警語

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前述合法通信，指依電信管理法規定作業之無線電通信。

低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

本產品內含發射器芯片：RTL8188FTV



CCAM21LP0180T2

安裝須知

1. 線材及主機安裝位置請遠離高壓點火線圈。
2. 線材及端口佈線時切勿嚴重彎折。
3. 不要用手指碰觸鏡頭。手指上的油垢可能會留在鏡頭上，導致影片或照片不清楚。請定期清潔鏡頭。
4. 本設備僅適用產品隨附之電源連接器，請勿使用其他廠牌以免設備燒毀。
5. 建議經由專業安裝廠安裝佈線。

安全注意事項

- ❖ 使用者須遵守當地法律並以行車安全為優先考量，請勿於行車中操作本設備。
- ❖ 使用設備前請先確認時區、日期與時間已設定完成。
- ❖ 本設備內建的韌體功能僅供使用者參考，道路駕駛請依實際路況作判斷。
- ❖ GPS 之定位結果僅供使用者參考，不應影響實際之駕駛行為，本設備無法確保其定位正確性。
- ❖ GPS 之定位正確性可能有所差異，包括受天候及使用地點（高樓 / 隧道 / 地下道 / 樹林）所影響。
- ❖ GPS 收訊品質與個別硬體特性有所不同，本設備無法判斷因硬體差異所造成的不同定位結果。
- ❖ 本設備顯示之時速和方位等數值會因外在環境因素影響而有所誤差，僅供使用者參考。
- ❖ 本產品僅供使用於非商業用途，適用法律允許的最大限度內。本公司對於使用本產品所造成的損失不承擔任何責任。
- ❖ Wi-Fi 訊號無法穿透建築物，訊號距離上限為 5 公尺。
- ❖ Wi-Fi 運作頻道表：Ch1~Ch13。

- ❖ 本產品運用無線資料通訊，可能會干擾鄰近的裝置，或受臨近裝置所干擾。
- ❖ 請勿在微波爐附近或任何會產生磁波及無線電干擾之處使用本產品。
- ❖ 在特定環境下無線電波效果接收可能較差。
- ❖ 請注意若有其他裝置也使用本產品所使用的 **2.4GHZ** 頻段，則兩者的處理速度皆有可能變慢。
- ❖ 本產品在使用時會略微變熱，純屬正常現象不代表故障。
- ❖ 不正確地使用本產品或操作不當導致設備或配件損壞，您的保固將會無效。
- ❖ 本產品的射頻可能干擾其他電子設備發出的射頻，產生負面影響並造成故障狀況。無線發射器和電路亦可能會干擾到其他電子設備，因此請遵守下列注意事項：
 - 飛機：當您搭乘飛機時，禁止使用無線發射器，請您關閉本產品的 **Wi-Fi** 功能。
 - 車輛：本產品發出的射頻可能會影響機動車輛中的電子系統，請您與該機動車的製造商或代理商洽詢車輛的問題。
 - 心律調節器：為避免對心律調節器造成潛在性的干擾，配戴心律調節器的人士應注意裝置啟用時，本產品與心律調節器之間的距離應保持在 **15 公分 (6 英寸)** 以上，並且請勿將本產品置於胸前口袋。若懷疑發生干擾現象時，請立即將本產品電源關閉。
 - 醫療裝置：若您使用任何個人醫療裝置，請詢問裝置製造商或醫生，確認您的裝置是否可充分屏蔽本產品發出的射頻。
 - 醫療機構：醫院和醫療機構可能使用對外射頻能量敏感的設備，當醫療人員或張貼的標誌指示您關閉會干擾射頻的設備時，請遵守指示。
 - 爆破區域與張貼告示的場所：若要避免干擾爆破作業，請在“爆破區域”或標示“關閉雙向無線電”的區域裡，遵守所有的標誌與指示關閉會干擾射頻的設備。
- ❖ **HP Inc.**對於操作中任何資料／內容的損失概不負責。
- ❖ 產品應用免責聲明
請掃描下方QR code並詳讀產品應用免責聲明。



開始使用本產品視為同意以上聲明事項。

1 導論







謝謝惠顧此套先進的行車記錄器(以下簡稱"設備")。本產品專用於機車行車時之即時錄影。

1.1 功能

- 智能降噪，有效降低環境音
- 前後超高畫質錄影防水鏡頭
- 星光級索尼超高清影像感應器
- **Wi-Fi** 及操作方便的 **app** 應用程式
- 主機及配件全套防水
- 一鍵鎖檔
- 自由黏貼 **GPS** 收訊最佳位置
- 碰撞或傾倒偵測，自動觸發緊急錄影


1.2 包裝內容

以下為包裝內容物。若有任何遺漏或損壞項目，請立即聯絡您的經銷商。

主機	前/後鏡頭	GPS
		
線控	電源線	安裝輔件包
		


1.3 產品概要

1.3.1 主機



編號	名稱	編號	名稱
1	Reset 復位孔	5	綠色: 連接GPS
2	microSD卡槽	6	藍色: 連接後鏡頭
3	連接線端子	7	黃色: 連接線控
4	紅色: 連接電源線	8	黑色: 連接前鏡頭

1.3.2 線控



編號	名稱	功能
1	前鏡頭指示燈	-指示燈長亮: 開機(未錄影) -指示燈一秒閃爍一次: 錄影中 -指示燈快閃: 前方測速照相提醒 (註)
2	後鏡頭指示燈	-指示燈長亮: 開機(未錄影) -指示燈一秒閃爍一次: 錄影中
3	麥克風	智能降噪
4	鎖檔/ Wi-Fi	-短按: 一鍵啟動緊急錄影並鎖檔 -長按: 開啟 Wi-Fi


註：

1. 測速照相提醒的功能必須設備的 GPS 內建該國或該地區的測速照相圖資，若無內建圖資，則此功能無法作用。未安裝 GPS，此功能亦無作用。測速照相提醒僅供使用者參考，不保證涵蓋行駛路線上的全部測速照相點，道路駕駛請依實際路況作判斷。
2. 是否內建測速照相圖資視國家或區域而定。詳洽經銷商。

1.4 使用儲存媒體

1.4.1 插入記憶卡

將記憶卡之金色接腳面朝前，以及主機銘版面朝上，如圖示插入記憶卡。



1.4.2 取出記憶卡

若主機在開機狀態請先關閉電源，並等待主機完成關機程式後再取出記憶卡。

註：


1. 主機在開機狀態時，不要取出或插入記憶卡，以免損壞記憶卡。
2. 限使用 microSD 速度等級V30以上，且內存容量 16GB 以上的 microSD 卡(最高支持 128GB)。
3. 使用前請先使用Go Moto app同步時間及格式化 microSD 卡。
4. 請定期同步時間及格式化記憶卡(建議一個月一次)

1.5 安裝



以下安裝可供參考，建議由專業人士進行安裝。

1.5.1 主機連接配件及電源線

按端子顏色將配件及電源線與主機連接。




1.5.2 安裝位置



編號	名稱	安裝位置
1	前鏡頭	可固定於龍頭或是車前擋板中心點。
2	線控	可固定至接近把手處，方便操作(參考上圖)。線控收音孔請勿朝前
3	GPS	可固定至收訊較佳處。
4	後鏡頭	可固定於車牌上方或後把手附近。
5	佈線	使用安裝輔件包佈線，前鏡頭線及電源線，線控線，GPS線走A柱兩側至後置物箱。
6	主機及線材	主機，電源線，前/後鏡頭線，線控線，GPS線，全放入置物箱內。主機可使用魔鬼氈固定於內側，方便抽取記憶卡。 *主機安裝完成，請使用 Go Moto app 校正傾倒偵測。

1.5.3 安裝電源線



1.5.4 調整與校正

安裝完成，請使用 Go Moto app 同步手機時間，設定時區，調整前後鏡頭的視角，並且校正主機的傾倒偵測。詳閱 2.設定。

2 設定

2.1 下載應用程式

初次使用請先使用手機下載並安裝 **[Go Moto]** 應用程式。

1. 從網路 **Google Play** 或 **App Store** 下載 **Go Moto**  應用程式。
2. 完成安裝。

應用程式的介面和功能可能會因應用程式版本的不同而改變，詳情請參訪 **Google Play** 或 **APP Store** 的更新。

2.2 Wi-Fi 連線

1. 長按線控3秒可開啟Wi-Fi。
2. 使用手機Wi-Fi功能，搜尋hp_m550_123456(後六碼為隨機碼)，點選確認之後，輸入密碼**12345678**，開始連結m550主機。
3. 使用手機已下載的app **Go Moto**開始設定或是操作其他功能。

註：

1. 主機開啟電源三分鐘內Wi-Fi是開啟的，如果您沒有使用[Go Moto]，則三分鐘後主機會自動關閉Wi-Fi。若要再次開啟，可長按線控3秒。
2. 行動裝置與記錄器連線需在 5 公尺以內，並且沒有建築物阻隔。
3. [Go Moto] 應用程式的語言將與您的行動裝置一致，非內建語言則為預設。

2.3 使用應用程式

觸碰行動裝置的 **Go Moto**







圖示，開啟應用程式，出現主畫面後，可依個人喜好進行設定或操作。



2.3.1 相機預覽/翻轉畫面，錄影及拍照

您可以使用此功能預覽及翻轉行車記錄器的畫面，啟動錄影或是拍照。






	圖示	敘述
1		錄影/暫停錄影
2		拍照（無論是前鏡頭預覽或是後鏡頭預覽，按下拍照鍵，前後鏡頭都會拍照）
3		切換前後鏡頭預覽
4	前鏡頭設定	翻轉鏡頭畫面
5	後鏡頭設定	翻轉鏡頭畫面

2.3.2 檔案播放，刪除及下載

您可以使用此功能播放或刪除行車記錄器拍攝的照片與影片，或是下載其照片與影片到您的行動裝置。



1. 觸碰主畫面下方的 【影片播放】或 【照片播放】。
2. 行動裝置螢幕會顯示行車記錄器儲存的檔案清單。行車記錄器將暫停錄影數秒，直到行動裝置讀取完記錄器內儲存的檔案。
3. 直接點選該影片或是照片，進行播放。
4. 若要刪除或下載，觸碰畫面右上方的”選取”，點選所需的影片或是照片，再點選下方圖標執行刪除或下載檔案。



	圖示	敘述
1		切換前後鏡頭檔案
2		下載檔案到行動裝置
3		刪除檔案
4		退出選單


註：

1. 若播放影片時，無法播放聲音，請檢查目錄設定是否開啟錄音功能，若已開啟錄音功能，表示該行動裝置不支援影音解碼並非檔案問題。如欲觀賞完整的影音，請將檔案下載至您的行動裝置，並為行動裝置安裝其它的影音應用程式，如VLC.....等，以播放下載的影片。
2. 刪除的檔案不能回復。刪除前請確保檔案留有備份。
3. 同時使用前後鏡頭拍照或錄影，所儲存的檔案，無論您只刪除前鏡頭檔案或是只刪除後鏡頭檔案，兩個前後鏡頭的檔案都會同時被刪除。
4. 下載的照片和影片會儲存在您的行動裝置的相簿，同時產生一個“Go Moto”的資料夾，您可以在該資料夾瀏覽檔案。

2.3.3 手機相簿



1. 觸碰主畫面下方的【手機相簿】。
2. 點選欲播放的影片或是照片執行播放。



3. 下載的照片和影片會儲存在您的行動裝置的相簿，同時產生一個“Go Moto”的資料夾，您可以在該資料夾瀏覽檔案。若要刪除該檔案，可在您行動裝置的相簿內刪除。

- 註：**
1. 刪除的檔案不能回復。刪除前請確保檔案留有備份。
 2. 若下載至行動裝置的影片檔案播放時沒有影音，表示該行動裝置不支援影音解碼並非檔案問題。建議您可以為行動裝置安裝其它的影音應用程式，如VLC.....等，以播放下載的影片。

2.3.4 相機設定

您可以使用此功能設定行車記錄器。



1. 觸碰主畫面下方的 **[相機設定]**。
2. 可用選單如表，請依個人需求或喜好進行設定。

目錄選項	描述	可用選單
手機時間同步	同步手機時間	是 / 否
時區設定	設定所在位置的時區，以便 GPS 衛星定位後可自動同步正確的日期時間。	GMT -12 ~ GMT +12
速度單位	設定速度單位。	Km/h, mph
車速顯示	可設定開啟或關閉車速顯示的浮水印。	開 / 關
測速照相提醒	若啟用測速照相提示，當衛星定位完成且車輛接近測速照相機時，線控指示燈會快閃。 *若無內建測速照相圖資，則此選項不會顯示。是否內建測速照相圖資視國家或區域而定。	開 / 關
錄影間隔	主機依循您所設定的影片長度將錄製的影片儲存為各個檔案。	1分鐘 / 3分鐘 / 5分鐘
聲音紀錄	設定錄影時是否錄音。	開 / 關
智能降噪	若開啟智能降噪，可降低背景聲，使人聲更清晰。	開 / 關
電源頻率	家用電源規格按地區不同，建議參考各國電壓頻率表作設定。	50Hz / 60Hz
傾倒偵測校正	主機安裝完成，請使用此功能校正三軸重力感應值(G-sensor)。	確定 / 取消
回復原廠設置	將系統回復到出廠的設定。	是 / 取消
格式化	將主機中的記憶卡格式化，所有的檔案都將喪失。	是 / 取消
連線設定	設定連線密碼。	
韌體版本	顯示行車記錄器當前韌體版本。	
APP 版本	顯示當前 APP 版本。	

3 SuperCar 2.0

請點選此連結 https://ftp.digilife.com.tw/SuperCar_2.0/SuperCar_2.0.zip 下載專屬影片/GPS播放器SuperCar 2.0 軟體。



編號	項目
1	播放前鏡頭錄影
2	瀏覽檔案
3	截圖
4	快退
5	播放/暫停
6	快進
7	音量
8	播放時長

編號	項目
9	重力值
10	播放後鏡頭錄影
11	軟件版本號
12	地圖(行車路徑)
13	檔案列表
14	更換語言及地圖系統
15	

註：

- 影片播放前須確認已連接網際網路，行車路徑才能於電子地圖顯示。
- SuperCar 2.0 軟體僅適用於 Windows 作業系統的電腦。

4 規格

項目	說明
影像感應器	1/2.8" 索尼星光級 CMOS 感應器
有效畫素	1920 (H) x 1080 (V)
儲存媒體	V30 以上速度的 microSD 卡, 最高可支持 128GB。
鏡頭	廣角定焦鏡頭 光圈：達 F1.55
對焦範圍	1.5m~無限遠
衛星系統	GPS (外接式)
影片檔	前鏡頭解析度：1080P/ 30 fps HDR 後鏡頭解析度：1080P/ 25 fps HDR
	格式：TS
照片檔	使用 App 拍照
	格式：JPG
重力感應器	3 軸重力感應器
ISO	自動
白平衡	自動
麥克風	內建
喇叭	無
電源	超級電容
操作溫度	-10° ~ 60° C
操作溼度	20 ~ 70% RH
儲存溫度	-20° ~ 70° C
主機尺寸	80 x 50 x 20 mm
主機重量	約 84 克

Wi-Fi 頻寬	2412~2484MHz
Wi-Fi 頻道列表	Ch1~Ch13
Wi-Fi 最大輸出	18dBm

5 限用物質含有情況說明書

設備名稱：機車行車記錄器		型號（型式）：m550				
Equipment name: Moto Cam		Type designation (Type)				
單元Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛Lead (Pb)	汞Mercury (Hg)	鎘Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁶⁺)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
主機外殼 及元件	○	○	○	○	○	○
主機內部電子元件	○	○	○	○	○	○
前後鏡頭外殼 及元件	○	○	○	○	○	○
前後鏡頭內部電子元 件	○	○	○	○	○	○
線材	○	○	○	○	○	○
備考1. “超出0.1 wt %”及“超出0.01 wt %”係指限用物質之百分比含量超出百分比含量基準值。 Note 1 : “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.						
備考2. “○”係指該項限用物質之百分比含量未超出百分比含量基準值。 Note 2 : “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.						
備考3. “-”係指該項限用物質為排除項目。 Note 3 : The “-” indicates that the restricted substance corresponds to the exemption.						



m550

机车行车记录器
使用说明书

目录

有关本手册	2
Regulatory notices.....	2
禁止同置	2
WEEE 通知.....	2
CE Regulatory Notice	2
安装须知	3
安全注意事项	3
1 导论.....	5
1.1 功能	5
1.2 包装内容	5
1.3 产品概要	6
1.3.1 主机	6
1.3.2 线控	6
1.4 使用储存媒体	7
1.4.1 插入记忆卡.....	7
1.4.2 取出记忆卡.....	7
1.5 安装	8
1.5.1 主机连接配件及电源线.....	8
1.5.2 安装位置	9
1.5.3 安装电源线.....	10
1.5.4 调整与校正.....	10
2 设定.....	11
2.1 下载應用程式	11
2.2 Wi-Fi 连线.....	11
2.3 使用應用程式	12
2.3.1 相机预览/翻转画面, 录像及拍照.....	13
2.3.2 档案播放, 删除及下载.....	14
2.3.3 手机相簿	16
2.3.4 相机设定	17
3 SuperCar 2.0.....	18
4 规格.....	19

有关本手册

本文件之内容只供参考，并得以随时变更不需要事先通知。本公司已尽全力确保本使用者手册正确与完整。但有任何错误或遗漏概不负责。制造厂保留不需事先通知，径自变更技术规格或配件之权利。

Regulatory notices

This document provides country- and region-specific non-wireless and wireless regulatory notices and compliance information for your product. Some of these notices may not apply to your product.

禁止同置

本产品及其天线不得在同一地点与任何其他天线、发射器同置或共同操作。

WEEE 通知

欧盟有关用户处分私人家庭废电子与电机产品和/或电池之指令



WEEE



Battery

产品上或包装上有此一符号，表示此产品不能做为家庭废弃物处理。您必须依据相关之电子与电机产品和/或电池回收办法之规定，处分您的废电子与电机产品和/或电池。有关这类产品和/或电池的回收细节，请联络当地的市政府、您购买该产品的商店或您的家庭废弃物处理公司。材料之回收有助于保护自然资源及确保能以保护人类健康与环境之方式回收。

CE Regulatory Notice

The product herewith complies with the requirements of IEC 62368-1:2014, the EMC Directive 2014/30/EU, the RED-Directive 2014/53/EU and the RoHS Directive 2011/65/EU.

EU Health Protection: This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

安装须知

1. 线材及主机安装位置请远离高压点火线圈。
2. 线材及端口布线时切勿严重弯折。
3. 不要用手指碰触镜头。手指上的油垢可能会留在镜头上，导致影片或照片不清楚。请定期清洁镜头。
4. 本设备仅适用产品随附之电源连接器，请勿使用其他厂牌以免设备烧毁。
5. 建议经由专业安装厂安装布线。

安全注意事项

- ❖ 使用者须遵守当地法律并以行車安全为优先考量，请勿于行車中操作本设备。
- ❖ 使用设备前请先确认时区、日期与时间已设定完成。
- ❖ 本设备内建的韧体功能仅供用户参考，道路驾驶请依实际路况作判断。
- ❖ **GPS** 之定位结果仅供使用者参考，不应影响实际之驾驶行为，本设备无法确保其定位正确性。
- ❖ **GPS** 之定位正确性可能有所差异，包括受天候及使用地点（高樓/ 隧道 / 地下道 / 树林）所影响。
- ❖ **GPS** 收讯质量与个别硬件特性有所不同，本设备无法判断因硬件差异所造成的不同定位结果。
- ❖ 本设备显示之时速和方位等数值会因外在环境因素影响而有所误差，仅供使用者参考。
- ❖ 本产品仅供使用于非商业用途，适用法律允许的最大限度内。本公司对于使用本产品所造成的损失不承担任何责任。
- ❖ **Wi-Fi** 讯号无法穿透建筑物，讯号距离上限为 5 公尺。
- ❖ **Wi-Fi** 运作频道表：**Ch1~Ch13**。
- ❖ 本产品运用无线数据通讯，可能会干扰邻近的装置，或受临近装置所干扰。
- ❖ 请勿在微波炉附近或任何会产生磁波及无线电干扰之处使用本产品。
- ❖ 在特定环境下无线电波效果接收可能较差。
- ❖ 请注意若有其他装置也使用本产品所使用的 **2.4GHZ** 频段，则两者的处理速度皆有可能变慢。
- ❖ 本产品在使用时会略微变热，纯属正常现象不代表故障。
- ❖ 不正确地使用本产品或操作不当导致设备或配件损坏，您的保固将会无效。

- ❖ 本产品的射频可能干扰其他电子设备发出的射频，产生负面影响并造成故障状况。无线发射器和电路亦可能会干扰到其他电子设备，因此请遵守下列注意事项：
 - 飞机：当您搭乘飞机时，禁止使用无线发射器，请您关闭本产品的 **Wi-Fi** 功能。
 - 车辆：本产品发出的射频可能会影响机动车辆中的电子系统，请您与该机动车的制造商或代理商洽询车辆的问题。
 - 心律调节器：为避免对心律调节器造成潜在性的干扰，配戴心律调节器的人士应注意装置启用时，本产品与心律调节器之间的距离应保持在 **15 公分 (6 英寸)** 以上，并且请勿将本产品置于胸前口袋。若怀疑发生干扰现象时，请立即将本产品电源关闭。
 - 医疗装置：若您使用任何个人医疗装置，请询问装置制造商或医生，确认您的装置是否可充分屏蔽本产品发出的射频。
 - 医疗机构：医院和医疗机构可能使用对外部射频能量敏感的设备，当医疗人员或张贴的标志指示您关闭会干扰射频的设备时，请遵守指示。
 - 爆破区域与张贴告示的场所：若要避免干扰爆破作业，请在“爆破区域”或标示“关闭双向无线电”的区域里，遵守所有的标志与指示关闭会干扰射频的设备。
- ❖ **HP Inc.**对于操作中任何数据 / 内容的损失概不负责。
- ❖ **产品应用免责声明**
请扫描下方二维码并详读产品应用免责声明



开始使用本产品视为同意以上声明事项。

1 导论







谢谢惠顾此套行车记录器(以下简称“设备”)。本产品专用于机车行车时之实时录像。

1.1 功能

- 智能降噪，有效降低环境音
- 前后超高画质录像防水镜头
- 星光级索尼超高清影像传感器
- **Wi-Fi** 及操作方便的 **app** 应用程式
- 主机及配件全套防水
- 一键锁档
- 自由黏贴 **GPS** 收讯最佳位置
- 碰撞或倾倒侦测，自动触发紧急录像


1.2 包装内容

以下为包装内容物。若有任何遗漏或损坏项目，请立即联络您的经销商。

主机 	前/后镜头 	GPS 
线控 	电源线 	安装辅件包 


1.3 产品概要

1.3.1 主机



编号	名称	编号	名称
1	Reset 复位孔	5	绿色: 连接GPS
2	microSD卡槽	6	蓝色: 连接后镜头
3	连接线端子	7	黄色: 连接线控
4	红色: 连接电源线	8	黑色: 连接前镜头

1.3.2 线控



编号	名称	功能
1	前镜头指示灯	-指示灯长亮: 开机(未录像) -指示灯一秒闪烁一次: 录像中 -指示灯快闪: 前方测速照相提醒 (注)
2	后镜头指示灯	-指示灯长亮: 开机(未录像) -指示灯一秒闪烁一次: 录像中
3	麦克风	智能降噪
4	锁档/ Wi-Fi	-短按: 一键启动紧急录像并锁文件 -长按: 开启 Wi-Fi


注：

1. 测速照相提醒的功能必须设备的 GPS 内建该国或该地区的测速照相图资，若无内建图资，则此功能无法作用。未安装 GPS，此功能亦无作用。测速照相提醒仅供使用者参考，不保证涵盖行驶路线上的全部测速照相点，道路驾驶请依实际路况作判断。
2. 是否内建测速照相图资视国家或区域而定。详洽经销商。

1.4 使用储存媒体

1.4.1 插入记忆卡

将记忆卡之金色接脚面朝前，以及主机铭版面朝上，如图标插入记忆卡。



1.4.2 取出记忆卡

若主机在开机状态请先关闭电源，并等待主机完成关机程序后再取出记忆卡。

注：


1. 主机在开机状态时，不要取出或插入记忆卡，以免损坏记忆卡。
2. 限使用 microSD 速度等级V30以上，且内存容量 16GB 以上的 microSD 卡(最高支持 128GB)。
3. 使用前请先使用Go Moto app同步时间及格式化 microSD 卡。
4. 请定期同步时间及格式化记忆卡(建议一个月一次)

1.5 安装



以下安装可供参考，建议由专业人士进行安装。

1.5.1 主机连接配件及电源线

按端子颜色将配件及电源线与主机连接。




1.5.2 安装位置



编号	名称	安装位置
1	前镜头	可固定于龙头或是车前挡板中心点。
2	线控	可固定至接近把手处，方便操作(参考上图) 线控收音孔请勿朝前。
3	GPS	可固定至收讯较佳处。
4	后镜头	可固定于车牌上方或后把手附近。
5	布线	使用安装辅件包布线，前镜头线及电源线，线控线，GPS线走A柱两侧至后置物箱。
6	主机及线材	主机，电源线，前/后镜头线，线控线，GPS线，全放入置物箱内。主机可使用魔鬼毡固定于内侧，方便抽取记忆卡。 *主机安装完成，请使用 Go Moto app 校正倾侧侦测。

1.5.3 安装电源线



1.5.4 调整与校正

安装完成，请使用 Go Moto app 同步手机时间，设定时区，调整前后镜头的视角，并且校正主机的倾倒侦测。详阅 2.设定。

2 设定

2.1 下载应用程序

初次使用请先使用手机下载并安装 **[Go Moto]** 应用程序。

1. 从网络 **Google Play** 或 **App Store** 下载 **Go Moto**  应用程序。
2. 完成安装。

应用程序的接口和功能可能会因应用程序版本的不同而改变，详情请参访 **Google Play** 或 **APP Store** 的更新。


2.2 Wi-Fi 连线

1. 长按线控3秒可开启Wi-Fi。使用手机Wi-Fi功能，搜寻hp_m550_123456(后六码为随机码)，点选确认之后，输入密码**12345678**，开始连结m550主机。
2. 使用手机已下载的app **Go Moto**开始设定或是操作其他功能。

注：

1. 主机开启电源三分钟内Wi-Fi是开启的，如果您没有使用**[Go Moto]**，则三分钟后主机会自动关闭Wi-Fi。若要再次开启，可长按线控3秒。
2. 行动装置与纪录器连线需在5公尺以内，并且没有建筑物阻隔。
3. **[Go Moto]** 应用程序的语言将与您的行动装置一致，非内建语言则为默认。


2.3 使用应用程序

触碰行动装置的 **Go Moto**  图标，开启应用程序，出现主画面后，可依个人喜好进行设定或操作。



2.3.1 相机预览/翻转画面，录像及拍照

您可以使用此功能预览及翻转行车记录器的画面，启动录像或是拍照。






	图示	叙述
1		录像/暂停录像
2		拍照 (无论是前镜头预览或是后镜头预览，按下拍照键，前后镜头都会拍照)
3		切换前后镜头预览
4	前镜头设定	翻转镜头画面
5	后镜头设定	翻转镜头画面

2.3.2 档案播放，删除及下载

您可以使用此功能播放或删除行车记录器拍摄的照片与影片，或是下载其照片与影片到您的行动装置。



1. 触碰主画面下方的 【影片播放】或 【照片播放】。
2. 行动装置屏幕会显示行车记录器储存的档案列表。行车记录器将暂停录像数秒，直到行动装置读取完记录器内储存的档案。
3. 直接点选该影片或是照片，进行播放。
4. 若要删除或下载，触碰画面右上方的“选取”，点选所需的影片或是照片，再点选下方图标执行删除或下载文件。




	图示	叙述
1		切换前后镜头档案
2		下载文件到行动装置
3		删除档案
4		退出选单


注：

1. 若播放影片时，无法播放声音，请检查目录设定是否开启录音功能，若已开启录音功能，表示该行动装置不支持影音译码并非档案问题。如欲观赏完整的影音，请将档案下载至您的行动装置，并为行动装置安装其它的影音应用程式，如VLC.....等，以播放下载的影片。
2. 删除的档案不能回復。删除前请确保档案留有备份。
3. 同时使用前后镜头拍照或录像，所储存的档案，无论您只删除前镜头档案或是只删除后镜头档案，两个前后镜头的档案都会同时被删除。
4. 下载的照片和影片会储存在您的行动装置的相簿，同时产生一个“Go Moto”的文件夹，您可以在该文件夹浏览档案。

2.3.3 手机相簿



1. 触碰主画面下方的  [手机相簿]。
2. 点选欲播放的影片或是照片执行播放。



3. 下载的照片和影片会储存在您的行动装置的相簿，同时产生一个“Go Moto”的文件夹，您可以在该文件夹浏览档案。若要删除该档案，可在您行动装置的相簿内删除。

注：

1. 删除的档案不能回复。删除前请确保档案留有备份。
2. 若下载至行动装置的影片档案播放时没有影音，表示该行动装置不支持影音译码并非档案问题。建议您可以为行动装置安装其它的影音应用程式，如VLC.....等，以播放下载的影片。

2.3.4 相机设定

您可以使用此功能设定行车记录器。



1. 触碰主画面下方的 **[相机設定]**。
2. 可用选单如表，请依个人需求或喜好进行设定。

目录选项	描述	可用选单
手机时间同步	同步手机时间	是/ 否
时区设定	设定所在位置的时区，以便 GPS 卫星定位后可自动同步正确的日期时间。	GMT -12 ~ GMT +12
速度单位	设定速度单位。	Km/h, mph
车速显示	可设定开启或关闭车速显示的水印。	开 / 关
测速照相提醒	若启用测速照相提示，当卫星定位完成且车辆接近测速照相机时，线控指示灯会快闪。 *若无内建测速照相图资，则此选项不会显示。是否内建测速照相图资视国家或区域而定。	开 / 关
录像间隔	主机依循您所设定的影片长度将录制的影片储存为各个档案。	1分钟 / 3分钟 / 5分钟
声音纪录	设定录像时是否录音。	开 / 关
智能降噪	若开启智能降噪，可降低背景声，使人声更清晰。	开 / 关
电源频率	家用电源规格按地区不同，建议参考各国电压频率表作设定。	50Hz / 60Hz
倾倒侦测校正	主机安装完成，请使用此功能校正三轴重力感应值(G-sensor)。	确定 / 取消
回复原厂设置	将系统回复到出厂的设定。	是 / 取消
格式化	将主机中的记忆卡格式化，所有的档案都将丧失。	是 / 取消
连线设定	设定连线密码。	
韧体版本	显示行车记录器当前韧体版本。	
APP 版本	显示当前 APP 版本。	

3 SuperCar 2.0

请点此连结 https://ftp.digilife.com.tw/SuperCar_2.0/SuperCar_2.0.zip 下载
专属视频/GPS播放器SuperCar 2.0 软件。



编号	项目
1	播放前镜头录像
2	浏览档案
3	截图
4	快退
5	播放/暂停
6	快进
7	音量
8	播放时长

编号	项目
9	重力值
10	播放后镜头录像
11	软件版本号
12	地图(行车路径)
13	档案列表
14	更换语言及地图系统

注:

1. 视频播放前须确认已连接网络，行车路径才能于电子地图中显示。
2. SuperCar 软件仅适用于 Windows 操作系统的电脑。

4 规格

项目	说明
影像传感器	1/2.8" 索尼星光级 CMOS 传感器
有效画素	1920 (H) x 1080 (V)
储存媒体	V30 以上速度的 microSD 卡, 最高可支持 128GB。
镜头	广角定焦镜头 光圈: 达 F1.55
对焦范围	1.5m~无限远
卫星系统	GPS (外接式)
影片檔	前镜头分辨率: 1080P/ 30 fps HDR 后镜头分辨率: 1080P/ 25 fps HDR
	格式: TS
照片檔	使用 App 拍照
	格式: JPG
重力传感器	3 轴重力传感器
ISO	自动
白平衡	自动
麦克风	内建
喇叭	无
电源	超级电容
操作温度	-10° ~ 60° C
操作湿度	20 ~ 70% RH
储存温度	-20° ~ 70° C
主机尺寸	80 x 50 x 20 mm
主机重量	约 84 克

内建 IEEE 802.11g/n(HT20) Wi-Fi芯片: RTL8188FTV

Wi-Fi 带宽	2412~2484MHz
Wi-Fi 频道列表	Ch1~Ch13
Wi-Fi 最大输出	18dBm